

SKMEI (Model 1100) DIGITAL WATCH INSTRUCTIONS



Four buttons on this watch are known as: **LIGHT**, **MODE**, **RESET**, and **START**

TO SELECT THE DISPLAY MODE

Push the Mode Button in order to select one of the following four display modes in the following order: **Normal Time** -> **Stop Watch** -> **Alarm Set**, -> **Time Reset**

In the Normal Time Mode, the Day of Week, the Hour, Minute and Second are displayed (none flash). If the alarm icon at the bottom left is displayed, the alarm is turned on.

TO DISPLAY THE DATE

In Normal Time Mode, Press the **START** button.

TO DISPLAY THE ALARM TIME

In Normal Time Mode, push the **RESET** button.

A P indicates PM, an A indicates AM. H indicates a 24 hour clock.

If the time is set as a 24 hour clock, the alarm will also show only as 24 hours with a H.

TO STOP/START THE ALARM

In Normal Time Mode, hold the **RESET** button while pressing the **START** button to toggle the Alarm icon on and off.

TO STOP/START THE HOURLY CHIME

In Normal Time Mode, hold the **RESET** button while pressing the **MODE** button to toggle the hourly chime on and off. When all the **days of the week** are displayed, the hourly chime is on.

TO SET THE TIME

Press the **MODE** button **x 3** until the hour is flashing.

To set the **Minute** press the **RESET button x 1**. Press the **START** button to increase the minutes.

Press the **RESET** button again to toggle through **Hours -> Date -> Month -> Day of Week -> Seconds**

Press the **START** button to increase the setting you are on.

TO SET THE ALARM

Note: The alarm is turned on every time the Alarm is set.

Press the **MODE** button **x 2** until the hour is flashing.

Press the **START** button to increase the hours

Press the **RESET** button to select minutes.

Press the **START** button to increase the minutes

A P indicates PM, an A indicates AM. H indicates a 24 hour clock.

If the time is set as a 24 hour clock, the alarm will also show only as 24 hours with a H.

Press the **MODE** button to finish and return to the time.

TO USE THE STOP WATCH

Press the **MODE** button **x 1**

Press the **START** button to start timing.

Press the **RESET** button to reset the stop watch to zero.

To record a LAP time, press the **RESET** button when the stop watch is running. Press **RESET** again to return to the live stop watch.